

# BOMBARDIER SEAT COVERS

To place an order please email [info@charmans.co.nz](mailto:info@charmans.co.nz) or call us on **06 843 6969**.

**Please note:** Some items are non-returnable. When placing an order, you acknowledge you have read the conditions of the catalogue/sale.



YEAR		DESCRIPTION	CODE
2013	<u>CAN-AM</u>	<b>Can-Am DS 450XC BLACK</b>	BOM012
2012/2016	<u>COMMANDER</u>	<b>Can-Am Commander 800/1000 - BLK - <i>Seat Only</i></b>	BOM009
2012/2016		Can-Am Commander 800/1000 - CANVAS - BLK*	BOM009C
2012/2016		Can-Am Commander 800/1000 - PVC - BLK*	BOM009P
2012/2016		Can-Am Commander 800/1000 - CANVAS - BLK <i>Seat Only</i>	BOM009H
2012/2016		Can-Am Commander 800/1000 - PVC - BLK <i>Seat Only</i>	BOM009H1
		<i>*Seat &amp; Backrest</i>	
2016/2020	<u>DEFENDER</u>	<b>Can-Am Defender 800/1000 - Blk <i>Base Only</i> *</b>	BOM020
2016/2020		Can-Am Defender 800/1000 - Canvas - Blk <i>Base &amp; Backrest</i> *	BOM020C
2016/2020		Can-Am Defender 800/1000 PVC - Blk <i>Base &amp; Backrest</i> *)*	BOM020P
		<i>*Please specify if Driver or Passenger Seat is required</i>	
2016/2020	<u>DEFENDER</u>	Can-Am Defender 800/1000 - Canvas - Blk <i>Base Only</i> *	BOM020CC
2016/2020		Can-Am Defender 800/1000 - PVC - Blk <i>Base Only</i> *	BOM020PP
		<i>*Please specify if Driver or Passenger Seat is required</i>	
2016/2020	<u>DEFENDER</u>	<b>Can-Am Defender 800/1000 - BLK <i>Centre Seat</i></b>	BOM021
2016/2020		Can-Am Defender 800/1000 - CANVAS - BLK <i>Centre Seat</i>	BOM021C
2016/2020		Can-Am Defender 800/1000 - PVC - BLK <i>Centre Seat</i>	BOM021P
2019	<u>DEFENDER</u>	<b>CAN AM Defender XMR HD10 - CANVAS - BLK (<i>Back &amp; Base</i>)</b>	BOM025C
2019		CAN AM Defender XMR HD10 - PVC - BLK ( <i>Back &amp; Base</i> )	BOM025P
2004/2016	<u>OUTLANDER</u>	<b>Outlander 400 Can-Am - BLK</b>	BOM006
2004/2016		Outlander 400 Can-Am - CANVAS - BLK	BOM006C
2004/2016		Outlander 400 Can-Am - PVC - BLK	BOM006P
2006	<u>OUTLANDER</u>	<b>Outlander 330 &amp; 400 / Outlander Max 400 - BLK</b>	BOM002*
2006		Outlander / Outlander Max - CANVAS - BLK	BOM002C
2006		Outlander / Outlander Max - PVC - BLK	BOM002P
2006		<b>Outlander - <i>Pillion Seat</i> - BLK</b>	BOM003
2006		Outlander - <i>Pillion Seat</i> - CANVAS - BLK	BOM003C
2006		Outlander - <i>Pillion Seat</i> - PVC - BLK	BOM003P
2006		<b>Outlander - <i>Back Pad</i> - BLK</b>	BOM004
2006		Outlander - <i>Back Pad</i> - CANVAS - BLK	BOM004C
2006		Outlander - <i>Back Pad</i> - PVC - BLK	BOM004P
2006/2012	<u>OUTLANDER</u>	<b>Outlander &amp; Max 650 VINYL - BLK (<i>Back Seat Only</i>)</b>	BOM011
2006/2012		Outlander & Max 650 CANVAS - BLK ( <i>Back Seat Only</i> )	BOM011C
2006/2012		Outlander & Max 650 PVC - BLK ( <i>Back Seat Only</i> )	BOM011P

# BOMBARDIER SEAT COVERS

To place an order please email [info@charmans.co.nz](mailto:info@charmans.co.nz) or call us on **06 843 6969**.

**Please note:** Some items are non-returnable. When placing an order, you acknowledge you have read the conditions of the catalogue/sale.



YEAR		DESCRIPTION	CODE
2006/2012	<b>OUTLANDER</b>	<b>Outlander &amp; Max 500/650/800 - BLK</b>	BOM005
2006/2012		Outlander & Max 500/650/800 - CANVAS - BLK	BOM005C
2006/2012		Outlander & Max 500/650/800 - PVC - BLK	BOM005P
2013/2019	<b>OUTLANDER</b>	<b>Outlander &amp; Max 500/650/800/1000XT Can-Am - BLK</b>	BOM008
2013/2019		Outlander & Max 500/650/800/1000XT Can-Am - CANVAS - BLK	BOM008C
2013/2019		Outlander & Max 500/650/800/1000XT Can-Am - PVC - BLK	BOM008P
2006/2012	<b>OUTLANDER</b>	<b>Outlander Max 550-1000 - VINYL - BLK (<i>Backrest</i>)</b>	BOM013
2006/2012		Outlander Max 550-1000 - CANVAS - BLK ( <i>Backrest</i> )	BOM013C
2006/2012		Outlander Max 550-1000 - PVC - BLK ( <i>Backrest</i> )	BOM013P
2013	<b>OUTLANDER</b>	<b>Outlander G2 500/650/800/1000XT - BLACK</b>	BOM113
2013		Outlander G2 500/650/800/1000XT - CANVAS - BLK	BOM113C
2013		Outlander G2 500/650/800/1000XT - PVC - BLK	BOM113P
2014/2015	<b>OUTLANDER</b>	<b>Outlander Max - Vinyl - BLK (<i>Back Seat</i>)</b>	BOM014
2014/2015		Outlander Max - Canvas - BLK ( <i>Back Seat</i> )	BOM014C
2014/2015		Outlander Max - PVC - BLK ( <i>Back Seat</i> )	BOM014P
2016/2020	<b>OUTLANDER</b>	<b>Outlander 450/570/800 - THATCH VINYL - BLK</b>	BOM022
2016/2020		Outlander 450/570/800 - CANVAS - BLK	BOM022C
2016/2020		Outlander 450/570/800 - PVC - BLK	BOM022P
2006/2009	<b>RENEGADE</b>	<b>Renegade 500/800 Can-Am - BLK</b>	BOM010
2006/2009		Renegade 500/800 Can-Am - CANVAS - BLK	BOM010C
2006/2009		Renegade 500/800 Can-Am - PVC - BLK	BOM010P
1998/2005	<b>TRAXTER</b>	<b>Traxter 500 Foot Shift - BLK</b>	BOM001*
1998/2005		Traxter 500 - CANVAS - BLK	BOM001C
1998/2005		Traxter 500 - PVC - BLK	BOM001P
2003	<b>QUEST</b>	<b>Quest 500 - BLK</b>	BOM007
2003		Quest 500 - CANVAS - BLK	BOM007C
2003		Quest 500 - PVC - BLK	BOM007P